Portable Thermal Printer User's Manual







Attentions:

- The printer should be away from the water and avoid the sunlight, glare and heat source direct exposure. Avoid any liquid, dust and metal objects into the interior of the printer.
- 2. The high environment temperature (>45°C) or the low temperature(<5°C) will reduce the print quality.
- 3. The high humidity (>85%RH) or the low humidity (<20%RH) will reduce the print quality.
- 4. Don't open the cover of paper bin in printing process.
- 5. Using low quality or storage too long time print paper will reduce the print quality, even damage the printer.

7. Don't touch the print head and retainer directly in order to avoid damaging

10. In the course of any accident, please disconnect the printer power supply.

- 6. If there is dirt at the print head, need to use a soft cotton or cotton swab to dip alcohol and wipe it clean to prevent the print head from being worn.
- the print head because of static electricity. Don't scratch or touch the print head with a hardened object to avoid damaging
- 8. Please try to use up the battery before charging, which can effectively protect the battery life
- 9. Please using the power supply attached to the product, or else, it maybe damage the printer or cause the charging time to extend.
- and remove the printer battery immediately. 11. If user disassemble the printer, the company has the right to refuse
- warranty on the product.
- ▲ This printer uses a thermal resistance to detect the temperature of the print head. If the print head is overheated, the circuit will cut off the power and stop printing. The overheat temperature of the print head is 80°C.

Storage precautions:

- 1. If not to use the printer for a long time, please be sure to remove the battery from printer, and disconnect the charger's power supply.
- 2. The storage time of printing content is short using the ordinary thermal printing paper. If you want to print the long-term preservation, please select the long-term thermal printing paper.
- 3. The thermal printing paper should not be stored in high temperature. humidity environment, or direct sunlight. If its package has been opened, please place it in the dark place.

1. Product introduction





2. Functions and features

Printing Method Thermal dot line printing

Resolution 203dpi,8 dots/mm

Printing Speed 90mm/s

Paeamters

	Printing Speed	90mm/s
	Wired	Standard :Micro-USB port
nmunication	Wireless	Optional:2.0 Bluetooth/SPP(for Android),4.0 Bluetooth (for iOS)
mmand Sets	/	ESC/POS Command sets
orage	RAM	4KB for receive buffer
лауе	FLASH	FLASH: 4MB, NV BMP FLASH:64 KB
	Chinese	GB18030 ,24x24
	Characters and figures	ASCII 9x17,12x24
aracters	User Defined	Support
	Language(code page)	Surport simplified & traditional Chinese, English, and other 45 kinks of international character sets.
		Support dots printing with different densities
oles	,	Support raster bitmap print
		Support to download the bitmap print ,the maximum size of each bitmap is not more than 64Kthe total size of the download is 64K.
rcode	1D	UPC-A,UPC-E,EAN-8.EAN13,CODE39,ITF,CODEBAR,CODE128,CODE93,etc
icode	2D	QR Code
tection	Sensor	Out of paper
icators	LED	Power(red), Battery charging/Out of paper(Green), Bluetooth(Blue)
	Туре	Standard thermal receipt paper or thermal table paper
nting	Width	57.5±0.5mm
aper	Thickness	0.056~0.1mm(receipt paper), 0.1~0.12mm(table paper)
	External Diameter	40mm(Max)
	Paper Loading	Easy paper loading structure
	Paper Tore	Manual
	Operating Environment	Temperature: -10 °C ~50 °C ,Humidity:25%~80%RH
ysical atures	Storage Environment	Temperature:-40 ℃ ~70 ℃, Humidity:≤93%RH (40 ℃)
	Size	78mmx45mmx112mm((WxDxH)
	Weight	0.9Kg (printer&Battery)
liability	Print Head	150Km
ilability	Motor	360,000 hours
	Drivers	Windows(WIN7/WIN8/WIN10/Vista/XP/2000)
ftwares	Drivers	UBUNTU 12.04 32/64, UBUNTU 14.04 32/64
	Арр	Printer Setting Tool
wer	Battery	Rechargeable Li-ion Battery,7.4 V ,2000mAh
pplyr	Charger	Input:100-240 VAC/0.5A,50/50HZ;Output:12VDC/1A

3. Basic operation

3.1 Power on the printer

In power off status, press down the "Power on/off" button and hold on 2 seconds, then the printer will beeps once and into working status, the power indicator light (red).

Noted: If the "charging indicator (green)" of printer flashing, indicating that the battery power of the printer has been less than 20%, please charge it

3.2 Power off the printer

In power on status, press down the "Power on/off" button and hold on 2 seconds, the printer will beeps twice then power off. and all the indicators

3.3 Print self-test page

After the user gets the printer, the printer can be self-test to detect the current settings and working status.

When the printer is power off and the print paper is loaded correctly, press down the "Power on/off" button and "Feed" button simultaneously, after hearing a beep sound, release the two buttons, the printer will print a self-

The self-test page contains information about the current status of the printer, settings and printing examples, such as the battery power, Bluetooth PIN. Bluetooth BDA. printing language, program version, font, etc.

3.4 Feed paper(manual)

In the normal working status, press the "Feed" button, the printer will

3.5 Battery charging

After using a period of time, the printer's battery power will be consumed. when the printer's green indicator light flashing slowly, indicating that the battery power has less than 20% and need to charge in time. This printer uses a charger for battery charging which output 12VDC/1A. Full charge takes about 4 hours.

The battery charging method:

Insert the AC input plug of the charger into the AC power socket(100-240VAC, 50/60Hz) and insert the output plug into the power input socket of the printer(12VDC/1A). When charging, the green indicator will flash. When the battery power is sufficient or the battery is fully charged, the green indicator light goes out.

3.6 Paper loading method

Open the cover of paper bin, draw out the head of paper roll, and put it into the paper bin in the direction shown below.



4. Communication connection

4.1 By Bluetooth

This series of printers can be equipped with Bluetooth 2.0 (SPP) or Bluetooth 4.0 (BLE) communication function. Bluetooth 2.0 can support the communication with the mobile terminal based on the Android system and Bluetooth 4.0 can support the communication with the mobile terminal based on the Apple iOS system.

Bluetooth connection method: After power on the printer, use the mobile terminal or the other communication equipment with Bluetooth to search the printer, after selecting the corresponding printer, enter the Bluetooth PIN code to connect, after successful connection, can be used normally Usually Bluetooth PIN code is "0000", for more details, please refer to the

4.2 By USB port

Before using the USB port to printing communication, you need to use the USB cable to connect the printer and PC.

The USB port can be set to "virtual serial port" or "print port" modes. Usually, the "print port" mode doesn't need to install the driver, but the "virtual serial port" mode need it.

The USB port working mode switching method: (1) Power off the printer and load paper correctly → (2) Press down the "Power on/off" button and "Feed" button simultaneously loosen them until the printer finished "self test page" printing → (3) Press down the "Feed" button for 2 seconds again to complete the switch operation (at the bottom of the "self-test page" will have a corresponding description)

5. Accessories

Paper roll	
User's manual	

Note: the specific product assessories may be different from this list, if in doubt, please consult your supplier.

Appendix:

The instructions of indicate light and buzzer signal

The printer is provided with a buzzer and 3 indicating lights for prompting the printer status, the indicator lights are used to indicate the current state. of the printer, and the buzzer is used to indicate the change of the printer

The details are as follows:

on	Printer status	Power indicator	Out of paper indicator	Bluetooth indicator	Buzzer
button for off status	Power ON	NO	OFF	OFF	Beep 1 soun
button for on status	Power OFF	OFF	OFF	OFF	Beep 2 soun
g time	Standby	Slowly flash	OFF	OFF	
button in tatus	Feeding paper	NO	OFF	OFF	Beep 1 soun
	Enough paper	NO	OFF	OFF	
	Out of paper or open the paper bin cover	Slowly flash Slowly flash	Slowly flash	OFF	}
g date	Bluetooth connect	NO	OFF	NO	~
< 20%)	Low power status	OFF	Slowly flash	OFF	
arger	Charging	OFF	Quickly flash	OFF	₹
	Fully charged	OFF	NO	OFF	1
andby tin	tandby time of the printer is set to 0 second, then the printer will immediately into	0 second,the	n the printe	r will imme	diately into

ם ס ס

Contents of this manual without the permission of the company shall not be free to change and replication, we reserve the right to change the product, if user needs the product further information can contact directly with the supplier.