

DIGITAL THERMOMETER

To use the 306, remove the protective sheath, press the ON/DH(Data Hold) button and insert at least 1/2" of the stem into the testing area. Push the ON/DH button a second time and the temperature reading will automatically be held on the LCD display. "°F" (°C) will blink when DH is in operation. Pressing the ON/DH button a third time will return the 306 to normal operation. To save battery life, the 306 will automatically turn off after approximately 35 minutes.

Note:When turning the 306 on, the LCD will display the last reading before turning off for 2 seconds. Then it will display the current temperature.

Specifications:

Temperature Range...306 : - 40 ° to 300 °F
306X : - 40 ° to 150 °C
Resolution 0.1 °
Accuracy 1% full scale
Sampling Time 1.0 seconds
Battery (SR44)A044



Test Products International, Inc.

9615 SW Allen Blvd
Beaverton, OR 97005-4814 USA
Ph: 503-520-9197 Fax: 503-520-1225

The Value Leader
www.tpi-thevalueleader.com

MADE IN KOREA