SP620 Differential Manometer Smart Probe

Test Products International, Inc.



Connects to smart phone and uses the TPI Smart Probe App or the TPI View App

Perform differential pressure measurements

Up to 6 SP620 smart probes can connect to a single mobile device (most devices)

Timed UK Let/By - Tightness Test function (View App ONLY)

UK Working Pressure Test (View App ONLY)

3 Year Limited Warranty

Test the TPI Advantage

Visit www.tpieurope.com

TABLE OF CONTENTS

A. Introduction	. 1
B. Safety Considerations	. 1
C. Specifications	. 2
D. Instrument Overview	. 3
E. Maintenance	. 4
F. Trouble Shooting	. 4
G. Accessories	. 4
H. Warranty	. 5
I. Replacing Batteries	. 5

A. INTRODUCTION

- 1. Congratulations: Thank you for purchasing TPI products. The SP620 is easy to use and built to last. It is backed by a 3 year limited warranty.
- Product Description: The SP620 is a Differential Manometer Pressure "Smart Probe". It connects to your mobile device and uses the TPI Smart Probe App or TPI View App to display differential pressure readings. Data can be displayed, saved, logged, allocated to a specific job, exported & e-mailed in either pdf or csv depending on which app the SP620 is connected to.
- 3. Download either the SmartProbe or the View app from either the Apple App Store or the Google Play Store

SmartProbes App



B. SAFETY CONSIDERATIONS

- 1. Never attach the SP620 to a hot surface.
- 2. Always ensure the pressure being measured does not exceed the capability of the SP620.
- 3. Never use the SP620 to measure liquid pressure.
- 4. Do not expose the unit to damp environments for extended periods of time.

View App

C. SPECIFICATIONS

SP620 Sma	art Probe Differential Pressure Meter Specifications		
Input Type	Dual input differential		
Connection Type	1/4 inch barb		
Measurement Range	-150 mbar to 150mbar (-60 inH2O to 60 inH2O)		
Accuracy	+/-0.05 mbar (0 to 1 mbar) / +/-(1.5% + 20 digits) (> 1 mbar)		
	+/-0.02 inH2O (0 to 1 inH2O) / +/-(1.5% + 20 digits) (> 1 inH2O)		
Resolution	0.01 mbar / 0.01 inH2O		
Units of Measure	7 Units (mbar, inH2O, kPa, PSI, mmHg, inHg, mmH2O)		
Operating Temperature	-20°C to 50°C (-4°F to 122°F)		
Communication	Bluetooth version 4.2 (Use with TPI Smart Probe App)		
	FCC ID: QOQBGM113		
	IC: 5123A-BGM113		
	209-J00204		
Battery Type	AAA x 3		
Battery Life	80 hours typical		

D. INSTRUMENT OVERVIEW





The inputs are marked + and -. Any pressure connected to the - port will be subtracted from the + port.

For standard pressure / vacuum measurements use the + port only.

Use the + and - port when performing differential measurements.

E. MAINTENANCE

- 1. Clean the surface of the instrument with a damp cloth.
- 2. Replace the three AAA batteries when the low battery indicator appears.

F. TROUBLE SHOOTING

Symptom	Probable Cause
Pressure seems inaccurate.	 Check tubing for kinks or cuts. Low battery. Ensure connection with smart device is working.
SP620 does not turn on.	 Dead or low batteries. Not holding down power switch until unit turns on. Defective POWER ON switch.
SP620 displays "OL".	Pressure limit exceeded.

G. ACCESSORIES

Included Accessories		Optional Accessories		
Part Number	Description	Part Number	Description	
A620SP	Soft pouch	A925	Carrying case for 4 smart	
			probes	
		A930	Carrying case for 1 or 2	
			smart probes	

H. WARRANTY

This product is warranted to the purchaser against defects in material and workmanship for three years from the date of purchase.

Covered by Warranty: Repair parts and labor; or replacement of the product at company's option. Normal transportation charges to the purchaser are also covered.

Not Covered by Warranty: Damages to the product which are the result of abuse, improper use or maintenance are not covered. Any other expense, consequential damages, incidental damages, or incidental expenses including damages to property are not covered. Transportation expenses to the company are not covered.

To Obtain Warranty Performance: Include with the product: your name, address, phone number, written description of the problem and proof of purchase date. Carefully package and return to:

TPI, Inc. 9615 SW Allen Blvd. Beaverton, OR 97005 USA 503-520-9197 www.testproductsintl.com TPI Canada 342 Bronte Rd. S., Unit 6 Milton, Ontario L9T 5B7 Canada 905-693-8558 www.tpicanada.com

TPI, Europe Ltd.. Longley House, International Drive Southgate Crawley West Sussex RH10 6AQ England 44(0) 1293 530196 www.tpieurope.com

Implied Warranties: Any implied warranties including implied warranties of merchantability and fitness for a particular purpose, are limited in duration to three years from date of purchase. To the extent any provision of this warranty is prohibited by federal or state law and cannot be preempted, it shall not be applicable. This warranty gives you specific legal rights, and you may also have other rights which vary from country to country.

I. REPLACING BATTERIES

1. Turn the battery compartment screw counter clockwise until it is just above the compartment door. Lift on the screw to open the compartment.



- 2. Replace the three AAA batteries.
- 3. Re-install the battery cover and tighten the screw by turning it clockwise.

Test Products International, Inc.

9615 SW Allen Blvd., Ste. 104 Beaverton, OR 97005 Tel: 503-520-9197 www.testproductsintl.com

Test Products International, Ltd.

342 Bronte Road South, Unit #6 Milton Ontario Canada L9T 5B7 Tel: 905-693-8558 www.tpicanada.com

Test Products International Europe Ltd.

Longley House, International Drive Southgate, Crawley, West Sussex RH10 6AQ Tel:: +44 (0) 1293 530196 www.tpieurope.com