



621

Digital Manometer Instruction Manual



Table of Contents

Page 3	Introduction & Product Description
Page 4	Safety Considerations
Page 5	Technical Data & International Symbols
Page 6	Features & Benefits
Page 7	Pressure Conversion Table
Page 8	Step by Step Procedures
Page 9	Accessories & Specifications
Page 10	Maintenance
Page 11	Trouble shooting guide EC declaration of conformity

Introduction

Congratulations

Thank you for purchasing TPI brand products. This meter is easy to use and is built to last. It is backed by a 3 year limited warranty. Please remember to return your product warranty registration card.

Product Description

The TPI 621 is a hand held pressure meter with superior resolution .

The 621 measure over the range of -300.0 to +300.0 mbar. Each unit has a resolution of 0.01 mbar to ± 99.99 mbar and automatically auto-ranges above ± 99.99 mbar to 0.1 mbar resolution. Each model is supplied complete with carry pouch, battery and instruction manual.

Safety Considerations

WARNING: Please follow the manufacturer's test procedure whenever possible. Make sure the pressure to be measured is not outside the range of the TPI 621 meter.

ALWAYS

- Test the pressure meter before use to ensure it is operating properly
- Ensure that the connecting hose you are using is free from kinks or splits
- Double check all connections before testing

NEVER

- Connect the Instrument to an unknown pressure source if the source is twice the working pressure of the instrument the sensor will be damaged and may cause injury to the user
- Tamper with the instrument or attempt to modify it in any way. Otherwise, accident and injury may occur and the warranty becomes void.


Technical Data

Controls



Turns the 621 on. Hold down to turn unit off.

ZERO

Momentarily press the  button to “ZERO” the display (“ZERO” will flash on the lower left of the LCD)

=

Smoothing function to stabilize rapidly changing pressure readings

UNITS

Selects 7 units of pressure kPa, PSI, inHg, mmHg, inH₂O, mmH₂O, mbar



Turns the back light on (automatically turns off after 15 seconds)



Features & Benefits

- Autoranging - Provides high resolution & accuracy at low
- Auto Power Off - Powers off after 20 minutes to conserve battery life.
- Trim Mode - Smoothing function to stabilize erratic readings. It displays the average value of 4 values previously measured.
- Zero Function - Provides immediate push button zeroing for Speed and accuracy.
- Units - Change the display value in any one of the following engineering units. kPa, PSI, inHg, mmHg, inH2O, mmH2O and mbar.
- Back Light - Provides easy reading of LCD in low light areas.

Pressure Coverstion Table

	Atmos	bar	inHg	inH ₂ O	PSI	mmHg	mmH ₂ O	Pascals
Atmos	1	9.86923 $\times 10^{-1}$	3.34207 $\times 10^{-2}$	2.458 $\times 10^{-3}$	6.8046 $\times 10^{-2}$	1.316 $\times 10^{-3}$	0.9677 $\times 10^{-4}$	9.869 $\times 10^{-6}$
bar	1.01325	1	3.3864 $\times 10^{-2}$	2.491 $\times 10^{-3}$	6.8948 $\times 10^{-2}$	1.333 $\times 10^{-3}$	0.9807 $\times 10^{-4}$	1.000 $\times 10^{-5}$
inHg	29.9213	29.53	1	7.355 $\times 10^{-2}$	2.036	3.937 $\times 10^{-2}$	2.89567 $\times 10^{-3}$	2.953 $\times 10^{-4}$
inH ₂ O	406.8	401.48	13.60	1	27.68	0.5354	3.937 $\times 10^{-2}$	4.014 $\times 10^{-3}$
PSI	14.6955	14.504	0.4912	3.6127 $\times 10^{-2}$	1	1.934 $\times 10^{-2}$	1.422323 $\times 10^{-3}$	1.4503 $\times 10^{-3}$
mmHg	760	750.06	25.400	1.868	51.715	1	7.35433 $\times 10^{-2}$	7.502 $\times 10^{-3}$
mmH ₂ O	10.3327 $\times 10^3$	10.1976 $\times 10^3$	3.4544 $\times 10^2$	25.400	703.07	13.599	1	.101972
Pascals	1.01325 $\times 10^5$	1.000 $\times 10^5$	3.386 $\times 10^3$	2.491 $\times 10^2$	6.8948 $\times 10^3$	1.333 $\times 10^2$	9.8071	1

Step by Step Procedures

1. Press the 'ON' key and the LCD display will be activated and automatically zeroed (if it does not read 0.00 proceed as follows)
2. Momentarily Press the  key and the display should zero within +/- 0.05 if not repeat until it does
3. Connect pressure meter to installation or equipment to be tested using appropriate hose connection in accordance with the manufacturers instructions
4. The pressure reading will appear on the display. To activate the backlight in poor light conditions press the  key at any time
5. If the reading is erratic or changing activate the smoothing function by pressing the '=' key
6. To convert the displayed pressure reading to another engineering unit depress the 'UNIT' key anytime and scroll through to the desired units of pressure.

Accessories & Specifications

Standard accessories

9V battery	.A009
Soft Pouch	.A600
Rubber Boot	.A612

Optional Accessories

Large Zipped pouch	.A904
--------------------	-------

Specifications

Auto Range	-300.0 to +300.0 mbar -120.4 to 120.4 inH ₂ O
Accuracy	-40.2 to 40.2 inH ₂ O: $\pm(0.2\%$ of F.V.) <-40.2 & >40.2 inH ₂ O: $\pm(1\%$ of M.V.)
Over Pressure	Protected to 15 PSI
Power Supply	9V
Relative Humidity	0% to 80%
Operating Temp.	0°C to +40°C
Storage Temp.	-10°C to +50°C
Auto Power Off	20 Minutes
Input Type	Differential

Maintenance

Battery Replacement:

The 621 will display a battery symbol when the internal 9V battery needs replacement.

Replace battery as follows:

1. Ensure instrument is switched off
2. Loosen the six cross head screws on the back of the instrument
3. Remove the back cover
4. Remove old battery
5. Replace with new battery 9V NEDA 1604 or equivalent
6. Reassemble the instrument in reverse order from above being sure not to trap any wires between the two halves of the case
7. Re-fit the six cross head screws being sure not to over tighten

Cleaning: Use a mild detergent and a slightly damp cloth to clean the surfaces of the instrument.

Trouble Shooting Guide

Problem	Probable Cause
Unit does not zero	Zero button has not been pushed.
Unit still does not zero	If reading is greater than 0.05 and constantly fluctuates return to local Service Centre.
'Bat' appears on display	Replace battery immediately 9V NEDA 1505 or equivalent

EC Declaration of Conformity

This is to certify that model 621 conforms to the protection requirements of the council EMC directive 2014/30/EU, in the approximation of laws of the member states relating to Electromagnetic compatibility by application of the following standards
EN61326-1:2013

EN61326-2-1:2013

EN61000-3-2:2006+A1:2009+A2:2009

EN61000-3-3:2013

To ensure conformity with these standards, this instrument must be operated in accordance with the instructions and specifications given in this manual.



Shenzhen BST Technology Co., Ltd.
Shenzhen, China

Certificate of Compliance

Certificate No. : BST16064982A0001Y-1EC-1

Applicant : SUMMIT CO.,LTD
58, Gaetbeol-ro, Yeonsu-gu, Incheon, Korea

Manufacturer : SUMMIT CO.,LTD
58, Gaetbeol-ro, Yeonsu-gu, Incheon, Korea

Product Name : DIGITAL MANOMETER

Main Test Model : TPI 621

Test Standard : EN61326-1:2013
EN61326-2-1:2013
EN 61000-3-2:2014
EN61000-3-3:2013

As shown in the Test Report No. : BST16064982A0001Y-1ER-1.

The EUT described above has been tested by us with the listed standards and found in compliance with the council EMC directive 2014/30/EU. It is possible to use CE marking to demonstrate the compliance with this EMC Directive.

The certificate applies to the tested sample above mentioned only and shall not imply an assessment of the whole production.



Christina Deng
Manager
Jun. 21, 2016

Shenzhen BST Technology Co., Ltd.

Add: Building No.23-24, Zhiheng Industrial Park, Guanhou Road, Nantou, Nanshan District, Shenzhen, Guangdong, China

Certificate Search: <http://www.bst-lab.com>, Tel:400-882-9628, 8009990306, E-mail:christina@bstlab.com



Test Products International Europe Limited

Unit 6 Rutherford Way Ind. Estate, Crawley,
West Sussex. RH10 9LN

Tel: 01293 530196

Email: sales@tpieurope.com

copyright © 2019 Test Products International, Inc.